

Safety instruction regarding dangers of accident in the weaving hall

1. All machines are equipped with mandatory safeguards, for example end switches, locking mechanisms, tumblers and similar devices. Do not suspend any of the devices ensuring the safety.
2. Do not carry out any manipulation at the machines. In case of malfunctions, please inform the technical personnel.
3. Never open switch cabinets, not even for pushing triggered safety switches. All electrical disruptions may only be removed by the technical personnel.
4. Mind carefully, that only the prescribed material can be utilized for the performance of tests. Exclusively the material approved by the university may be used.
5. Stay away from feed rolls. Do not carry out any corrections at the feeding rolls. Disruptions may only be removed by the technical personnel.
6. Be careful that no clothing gets caught in the machine parts. Wear tight clothes and closed shoes.
7. Long hair must be securely tied back/up.
8. Be aware of chains, watches, rings, enlarged pieces of jewelry and accessories, also if they are attached at the clothing. Remove all possible sources of danger.
9. Use only prescribed auxiliaries at the machines.
10. Pay attention to the battens and reeds, due to the fact that the machines can perform several rotations after the STOP. Never reach into the machines.
11. Do not reach into the braiding machine. During operation, there is a high risk of injury, due to the fact that this machine is not equipped with light barriers.
12. At any time, follow the instructions of qualified personnel.
13. Do not climb on the machine frames. Enter this area only on request.
14. Use the emergency stop ("NOTAUS") in case of danger and inform the personnel.
15. In case of fire, inform the personnel and leave the danger zone orderly at the signed emergency exists.
16. Smoking is prohibited in the entire weaving hall.
17. Use hearing protection in case of very loud surroundings. Ear protectors can be found next to the door to the photo studio.
18. Do not play with compressed air. It is intended for cleaning the machines and should only be used by the personnel.